


HAMMERHEADTM

HYDRAULIC POWER SUPPLY UNITS



Parts Manual

POWER PACK PP13 s/n 101
POWER PACK PP20 s/n 101
POWER PACK PP73 s/n 101

Part No. PM1610

INTRODUCTION

HOW TO USE THE MANUAL

This manual contains illustrations and parts list of components and assemblies which make up the machine. Each page consists of the name of the assembly or component, a figure number, reference numbers, part numbers, part names, and the quantities of the parts used.

Assembly or component names help identify the illustration and parts for each figure. This name also helps locate the general area of the machine where the assembly or component can be located.

Figure numbers are used to identify each assembly or component and to group these assemblies or components into major categories.

Reference numbers shown in a column refers to the numbered parts in the illustration. This ties the part in the illustration to the part number and description in the parts list. Part numbers are used to identify individual parts or part assemblies.

Part descriptions provide the name of the part, plus additional information such as dimensional specifications and what parts are grouped together to form part assemblies, which helps you identify the part(s).

Quantities listed for each figure are only for that assembly or component and not the total used per machine unless stated so in the "Remarks" column.

Parts are listed by part number in numerical order in the back portion of the manual. After each part number is a list of references where the part is used in the manual.

This parts manual is not intended to be a complete guide for machine service or repairs. Contact your HammerHead dealer for any of your service or technical requirements.

ORDERING PARTS

Parts for repair or replacement are available through the worldwide network of authorized HammerHead dealers.

Use only authorized HammerHead parts for repair or replacement. Always give the serial number and model number of the machine for which parts are being

ordered. When ordering parts for component(s), which are not manufactured by HammerHead Manufacturing, also give the serial number of that component(s). Order all parts by part number, part name, and quantity needed.

UPDATING AND REORDERING MANUALS

The parts lists, illustrations, and specifications in this manual are based on the latest information available at the time of publication. Your machine may have product improvements and options not yet contained in this manual. Please check the web site www.hammerheadmole.com for any updates.

Earth Tool Co., LLC reserves the right to make changes at any time without notice or obligation to you.

Your dealer will receive notice of these changes and can assist you with accurate parts identification when ordering.


A copy of this manual is supplied with each machine. Additional copies are available through your dealer. When ordering additional manuals, use the reorder number listed on the front cover and the quantity needed.

TABLE OF CONTENTS

TABLE OF CONTENTS.....	1
POWER PACK - DECALS	2
POWER PACK, 20HP - DECAL LOCATIONS	4
POWER PACK , 73HP DECAL LOCATIONS.....	5
POWER PACK - 13 HP	6
POWER PACK, 20HP - HYDRAULIC, ELECTRIC & FUEL SYSTEM ASSEMBLY (1 OF 2)....	8
POWER PACK, 20 HP - ENGINE ASSEMBLY	12
POWER PACK, 20 HP - SHEET METAL ASSEMBLY	14
POWER PACK, 20 HP - HOSE & ADAPTER KIT	16
POWER PACK, 73 HP - SHEET METAL ASSEMBLY	18
POWER PACK, 73 - FUEL & ENGINE ASSEMBLY	20
POWER PACK, 73 - ENGINE ASSEMBLY	22
POWER PACK, 73 HP - HYDRAULIC ASSEMBLY	24
POWER PACK, 73 HP - ELECTRICAL ASSEMBLY	26
NUMMERICAL INDEX.....	28
ALPHABETICAL INDEX	31

POWER PACK - DECALS

Figure 1




SEE PAGE 4, PAGE 5, AND PAGE 6 FOR DECAL LOCATIONS.

POWER PACK - DECALS

NO.	PART NO.	DESCRIPTION	QTY	COMMENTS
1	296276-455	DECAL, TIE DOWN (SMALL)	4	
2	296276-472	DECAL, COOLANT WARNING	1	
3	296276-479	DECAL, FUSE PANEL, PP20	1	
4	296270-644	DECAL, WWW. HAMMERHEAD 6 X 4 TRIANGLE	1	
5	296276-477	DECAL, PP20	1	
6	296270-643	DECAL, HAMMERHEAD 30	1	
7	296276-469	DECAL, FALLING LOAD	1	
8	296276-492	DECAL, LIFT POINT (LARGE)	1	
9	296276-470	DECAL, WARNING (BATTERY)	1	
10	296270-645	DECAL WWW. HAMMERHEAD LARGE 12 X 8 TRI- ANGLE	2	
11	70000-684	DECAL, READ OPERATOR'S MANUAL	1	
12	296276-446	DECAL, WARNING, (ONE-CALL)	1	
13	70000098	DECAL, DIESEL FUEL	1	
14	296276-471	DECAL, REFUELING WARNING	1	
15	70000-294	DECAL, OPERATOR'S MANUAL	1	
16	2326-756	DECAL, HYDRAULIC OIL, PP20	1	
17	296276-478	DECAL, CONTROL PANEL, PP20	1	
18	296276-370	DECAL, PP73	1	
19	296276-371	DECAL, CONTROL PANEL, PP73	1	
20	296276-481	DECAL, FUSE, PP73	1	
21	ET912-3103	SERIAL NO. TAG, PP13	1	
22	296276-476	DECAL, VALVE CONTROL	1	
23	ET913-7253	DECAL, HOT	2	

POWER PACK, 20HP - DECAL LOCATIONS


Figure 2



SEE PAGE 2 FOR DECAL DESCRIPTIONS

POWER PACK , 73HP DECAL LOCATIONS

Figure 3




SEE PAGE 2 FOR DECAL DESCRIPTIONS

POWER PACK - 13 HP

Figure 4

This illustration includes decal locations.




POWER PACK - 13 HP

NO.	PART NO.	DESCRIPTION	QTY	COMMENTS
1	296271-950	RESERVOIR	1	
2	290853-001	PIPE PLUG, SQ HEAD 3/4 GALV	1	
3	296271-928	VALVE	1	
4	296271-943	BUSHING, 8MP X 4FP	1	
5	123645-001	ELBOW, 12MP-12MP X 90	1	
6	296271-929	FILTER HEAD	1	
7	296271-930	ELBOW, 12MP X 8FP 45 DEGREE	1	
8	296271-933	ADAPTER, 10MB X 8FP	1	
9	296271-931	FILTER	1	
10	296271-932	SHIELD	1	
11	296271-934	TEE, 8MP X 8FP X 8FP	1	
12	296271-945	ELBOW, 12 MP X 12BARB 90 DEGREE	2	
13	70000-684	DECAL, READ OPERATOR'S MANUAL (See PAGE 2)	1	
14	296271-951	PUMP, .388 CU IN.	1	
15	248890-001	GUAGE, 3000 PSI PRESSURE	1	
16	296271-937	PLATE, PUMP	1	
17	296271-949	ENGINE, 13 HP HONDA	1	
18	296271-941	COUPLER, PUMP	1	
19	296271-940	COUPLER, ENGINE	1	
20	296271-938	SPIDER	1	
21	296271-939	SPACER, MOUNT	2	
22	296271-942	SPACER, BOTTOM	2	
23	296271-952	CLAMP, HOSE 1-3/4	4	
24	296271-936	CAP	1	
25	296271-946	HOSE, RETURN	1	
26	296271-935	HOSE, SUCTION	1	
27	296271-947	ADAPTER, 12MP X 12 BARB	1	
28	296271-948	ADAPTER, 10MB X 12BARB	1	
30	296271-944	HOSE, PRESSURE	1	
31	296267-750	WHEEL & TIRE ASSEMBLY	2	
32	296270-612	COTTER PIN 3/16 X 1-1/14	4	
33	485-017	WASHER, FLAT 3/4, DP1698	4	
34	296276-476	DECAL, VALVE CONTROL (See Page PAGE 2)	1	
35	296270-644	DECAL, WWW.HAMMERHEAD 6X4 TRIANGLE (See PAGE 2)	2	
36	296271-927	CAGE	1	
37	296270-611	ELBOW, 8MF X 8MP 45	2	
38	296270-610	HOSE, 1/2" X 15 FT	2	
39	296267-726	NIPPLE 1/2	1	
40	296267-727	ADAPTER, COUPLER 1/2	1	
	70000-684	DECAL, READ OPERATOR'S MANUAL (INT)	1	

POWER PACK, 20HP - HYDRAULIC, ELECTRIC & FUEL SYSTEM ASSEMBLY (1 OF 2)


Figure 5



POWER PACK, 20HP - HYDRAULIC, ELECTRIC & FUEL SYSTEM ASSEMBLY

NO.	PART NO.	DESCRIPTION	QTY	COMMENTS
1	296274-910	AIR CLEANER SUPPORT	1	
2	296274-911	OIL TANK, 15 GAL	1	
3	296271-872	HEAD, FILTER	1	
4	296271-873	OIL FILTER, 50-AT	1	
5	296273-067	ENGINE, KUBOTA D905	1	
6	296271-775	PUMP, PVP33 2.0 CI	1	
7	296271-874	OIL COOLER	1	
8	229229-245	ISOLATOR, COOLER	4	
9	287563-00301	FUEL TANK	1	
10	296267-625	BATTERY, 12V GROUP 24 TOP POST 575 CC AMPS	1	
11	296273-084	BRACKET, BATTERY	1	
12	248848-001	BOLT, J- 1/4-20 X 9	2	
13	296273-095	EXHAUST PIPE	1	
14	296273-065	BRACKET, MUFFLER SUPPORT	1	
15	290997-001	CLAMP, EXHAUST 1-1/2	1	
16	241194-001	BOLT, HX HD 5/16-18 X 3/4	8	
17	409-001	NUT, 5/16-18 TOP LOCK	16	
18	296271-964	WASHER, 5/16" HARDENED	8	
19	4475-006	BOLT, FLANGE 3/8-16 X 3/4	6	
20	290504-001	NUT, 3/8-16 HEX GR 5	6	
21	296271-869	WASHER, 3/8" HARDENED	27	
22	296271-961	BOLT, HX HD M10-1.25 X 25mm CLASS 8.8	16	
23	4474-006	BOLT, HX HD SER FLG5/16-18X3/4	4	
24	296271-761	BOLT, CARRIAGE 1/4-20 X 3/4	25	
25	403-001	NUT, 1/4-20 TOP LOCK	26	
26	296271-826	WASHER, 1/4" HARDENED	38	
27	225861-001	CAP, FUEL	1	
28	296271-785	WASHER, 1/2" SAE HARDENED	6	
29	251769-001	BOLT, HX HD 1/2-20 X 1-3/4	4	
30	358-012	BOLT, HX HD 1/2-13 X 1-1/4	2	
31	279829-001	TEMP SWITCH, 210 DEGREE	1	
32	287564-001	ELBOW, HOSE 3/8	2	
33	75925-001	GROMMET	2	
34	296263-838	TUBE, 3/8 ID X 5/8 OD X 11	1	
35	406-001	NUT, 5/16-18 HEX	2	
36	296271-871	OIL CAP ASSY	1	
37	296271-870	SUCTION SCREEN, OIL TANK	1	
38	296271-768	RETURN FILTER PRESSURE SWITCH	1	
39	296273-069	CIRCUIT BREAKER, 30 AMP	1	
40	296271-972	FILTER, FUEL	1	

POWER PACK, 20HP - HYDRAULIC, ELECTRIC & FUEL SYSTEM ASSEMBLY (2 OF 2)




POWER PACK, 20HP - HYDRAULIC, ELECTRIC & FUEL SYSTEM ASSEMBLY

NO.	PART NO.	DESCRIPTION	QTY	COMMENTS
41	296276-473	BOOT, STRAIGHT CLAMP	1	
42	296273-073	SUPPORT, OIL TANK	2	
43	354-032	BOLT, HX HD 3/8-16 X 3-1/4	2	
44	296273-070	BATTERY CABLE, 4ga POSITIVE	1	
45	296273-071	BATTERY CABLE, 4ga NEGATIVE	1	
46	296278-467	CABLE, THROTTLE	1	
47	229229-309	PRESSURE GUAGE, 3000 PSI	1	
48	296273-085	VALVE, RELIEF ASSY	1	
49	350-020	BOLT, HX HD 1/4-20 X 2	2	
50	296273-066	VALVE, POPPET	1	
51	5537-001	TOGGLE BOOT	1	
52	296271-773	MODULE, WARNING LIGHT	1	
53	2986274-782	SWITCH, IGNITION	1	
54	296271-772	SWITCH, EMERGENCY STOP	1	
55	67292-001	SWITCH, TOGGLE SPST	1	
57	215914-001	HOUR METER	1	
58	229229-335	RECEPTACLE 12VDC	1	
59	248922-001	ISOLATOR, RUBBER 1/2-20 THRD	4	
60	296273-051	MOTOR MOUNT	4	
61	296273-097	HOSE, 1/4" X 4	1	
62	229229-195	FITTING, 1/4" NPT X 3/16" BARB	1	
63	296273-098	HOSE, 1/4" x 48	1	
64	296273-099	HOSE, 3/16" X 54	1	
65	229229-197	FITTING, 1/4" X 1/4 NPT BARB	1	
66	296271-969	HOSE, WATER 5/16 X 60	1	
67	1578-001	CLAMP, HOSE 1/4	8	
68	290908-001	CLAMP, HOSE 1/2	2	
69	229229-373,	BOLT, HX HD M6-1.00 X 15mm	2	
70	296274-881	BOOT, STUD TERMINAL	1	
71	296271-953	BOLT, HX HD 3/8-16 X 1	5	
72	296271-782	BOLT, HX HD M14-2.00 X 30mm	1	
74	296271-776	SCREW, PHILLIPS 10-32NF X 5/8	12	
75	296274-912	OIL TANK TRAY	1	
76	296274-913	STRAP, OIL TANK	1	
77	416-001	NUT, 3/8-16 TOP LOCK	13	
78	ET913-7053	FOAM, AIR FILTER	1	
NS	296273-068	HARNESS, PP20 WIRE	1	

POWER PACK, 20 HP - ENGINE ASSEMBLY

Figure 6




POWER PACK, 20 HP - SUB ASSEMBLY

NO.	PART NO.	DESCRIPTION	QTY.	COMMENTS
1	296278-462	STARTER	1	
2	218420-037	ALTERNATOR	1	
3	296278-460	ASSEMBLY, FUEL FILTER	1	
4	296278-464	FAN	1	
5	296278-461	CARTRIDGE, FUEL FILTER	1	
6	218420-055	ASSEMBLY, FUEL PUMP	1	
7	296253-038	AIR CLEANER ASSY	1	
8	227241-033	ASSEMBLY, WATER PUMP	1	
9	227241-005	CAP, VALVE COVER	1	
10	218420-015	O-RING, VALVE COVER CAP	1	
11	296274-794	THERMOSTAT	1	
12	296274-795	GASKET, THERMOSTAT	1	
13	296274-791	PLUG, OIL PAN DRAIN	1	
14	296274-792	GASKET, OIL PAN PLUG	1	
15	296274-788	HUB, PUMP DRIVE	1	
16	296274-789	ADAPTER, HYD PUMP	1	
17	296278-465	MUFFLER	1	
18	227241-011	GASKET-MUFFLER	1	
19	296274-784	BRACKET, WATER RESERVE TANK	1	
20	296274-785	ASSEMBLY, RESERVE TANK	1	
21	296278-466	RADIATOR ASSEMBLY	1	
22	296267-602	ELEMENT, AIR FILTER	1	
23	277241-038	ASSEMBLY, STOP SOLENOID	1	
24	227241-041	GASKET, STOP SOLENOID	1	
25	296274-782	SWITCH, IGNITION	1	
26	296278-467	CABLE, THROTTLE	1	
27	296274-786	SHROUD, FAN	1	
28	296274-790	VALVE, RADIATOR DRAIN ASSY	1	
29	227241-021	FILTER, ENGINE OIL	1	
30	296267-599	V-BELT, FAN	1	
31	296274-781	HOSE, AIR CLEANER	1	
32	218420-039	SWITCH, OIL	1	
33	296274-783	SWITCH, TEMPERATURE	1	

POWER PACK, 20 HP - SHEET METAL ASSEMBLY

Figure 7




POWER PACK, 20 HP - SHEET METAL ASSEMBLY

NO.	PART NO.	DESCRIPTION	QTY	COMMENTS
1	296273-050	BASE FRAME WELDMENT	1	
2	296273-052	BACK PANEL	1	
3	296273-053	COVER WELDMENT	1	
4	296273-054	PANEL, RH SIDE	1	
5	296273-055	PANEL, LH SIDE	1	
6	296273-056	COVER, CONTROL PANEL WELDMENT	1	
7	296273-060	RADIATOR PANEL	1	
8	296271-858	DOOR LATCH (LARGE)	1	
9	229229-059	DOOR LOCK (SHORT)	1	
10	296271-854	HINGE, 12.25	1	
11	296271-859	HANDLE	1	
12	296273-062	HINGE, 9.75	1	
13	296273-061	HINGE, 28.75	1	
14	248867-001	BRACKET, HOSE	2	
15	296273-057	FUEL TANK SUPPORT	1	
16	296273-064	CONTROL PANEL HOUSING	1	
17	296273-063	CONTROL PANEL WELDMENT	1	
18	296273-100	PANEL, RADIATOR	2	
19	248847-001	TRIM SEAL 3/8 BULB	4	
20	296276-480	PANEL, ACCESS	2	
21	296271-857	SPRING BRACKET	4	
22	296271-833	STUD, BALL	4	
23	296273-082	BAFFLE, RADIATOR	2	
24	296271-831	AIR CYLINDER, MAIN DOOR	2	
25	4473-004	BOLT, HX HD SER FLG 1/4-20 X 1/2	31	
26	296273-059	LIFT BAR	1	
29	375-010	BOLT, CARRIAGE 3/8-16 X 1	6	
31	296271-827	MOUNT, HYD. COOLER	2	
33	296273-080	BRACKET, GRILL	1	
34	296273-072	FOAM, PANEL	1	
35	142410-001	BOX, LITERATURE	1	
38	510-049	PIN, COTTER 3/32 X 1	2	
39	248912-001	TRIM SEAL 3/8 BULB 90 DEGREE	2	
40	98436-001	GASKET, DOOR (COMES IN 17' LGTH)	0.16	
41	296273-081	ROD, PROP	1	
NS	351-010	BOLT, HX HD 5/16-18 X 1	12	

POWER PACK, 20 HP - HOSE & ADAPTER KIT

Figure 8



POWER PACK, 20 HP - HOSE & ADAPTER KIT

NO.	PART NO.	DESCRIPTION	QTY	COMMENTS
1	248841-001	HOSE ASSY, 3/4" X 300	2	
2	248844-001	COUPLING, 3/4 FLUSH FACE	1	
3	248845-001	NIPPLE, 3/4" FLUSH FACE	1	
4	108500-001	BULKHEAD, 12MJ 90 DEGREE	2	
5	296271-817	ADAPTER, 32MB X 20FB	1	
6	296273-088	ADAPTER, 12MJ X 16MB	2	
7	296273-086	HOSE, 3/4" X 54	1	
8	85658-001	ADAPTER, 12MJ X 20MB	2	
9	296273-087	HOSE, 3/4" X 55	1	
10	296273-090	HOSE, 1/2" X 25	1	
11	53837-001	ELBOW, 8MJ X 8MB 90 DEGREE	1	
12	296273-092	ELBOW, 8MJ X 10MB 90 DEGREE	1	
13	296273-091	HOSE, 3/4" X 17	1	
14	296273-074	HOSE, 1/4" X 23	2	
15	296274-887	ADAPTER, 4MJ X 6MB	1	
16	60908-001	ADAPTER, 4MJ X 4MB	1	
17	296273-076	REDUCER, 6MB X 4FB	1	
18	296274-884	ADAPTER, 6MJ X 6MB	1	
19	296273-077	TEE, 4MJ X 4MJ X 4MB	1	
20	296273-079	HOSE, 1/4" X 14	1	
21	59423-001	ADAPTER, 4MJ X 4MB 90 DEGREE	1	
22	296271-999	ELBOW, 6MJ X 6MB 90 DEGREE	3	
23	296273-078	HOSE, 3/8" X 23	1	
24	296273-075	HOSE, 3/8" X 28	1	
25	296273-093	PLUG, 10MB	1	
26	296271-819	ADAPTER, 20MB X 16FP	1	
27	296274-870	PLUG, 2MP	3	
28	248849-001	CLAMP, T-BOLT 1-1/2	2	
29	296273-222	HOSE, 1-1/4"x41	1	
30	296273-074	HOSE, 1/4"x23	1	
31	296273-221	ELBOW, 1-1/4" HOSE INSERT	1	
32	296274-796	ADAPTER, 20MB X 1-1/4" BARB	1	

Figure 9


This exploded perspective view illustrates the assembly of a vehicle interior trim component. The main body (1) features a central panel (2) with a mesh grille (6) and a side panel (4). A front bezel (24) is shown with four circular cutouts. A rear panel (3) with a mesh grille (28) and a side panel (25) is also depicted. A central vertical support (30) is shown with a mesh grille (32) and a side panel (29). A front panel (13) with a mesh grille (26) and a side panel (27) is shown. A rear panel (14) with a mesh grille (35) and a side panel (31) is shown. A central vertical support (17) with a mesh grille (18) and a side panel (19) is shown. A front panel (7) with a mesh grille (11) and a side panel (9) is shown. A rear panel (10) with a mesh grille (12) and a side panel (15) is shown. A central vertical support (16) with a mesh grille (23) and a side panel (33) is shown. A front panel (21) with a mesh grille (22) and a side panel (20) is shown. A rear panel (23) with a mesh grille (24) and a side panel (25) is shown. A central vertical support (26) with a mesh grille (27) and a side panel (29) is shown. A front panel (30) with a mesh grille (31) and a side panel (32) is shown. A rear panel (32) with a mesh grille (33) and a side panel (35) is shown. A central vertical support (34) with a mesh grille (35) and a side panel (36) is shown.

POWER PACK, 73 HP - SHEET METAL ASSEMBLY

NO.	PART NO.	DESCRIPTION	QTY	COMMENTS
1	296276-345	BASE FRAME WELDMENT	1	
2	296276-343	BACK PANEL	1	
3	296276-346	SIDE PANEL, RH	1	
4	296276-347	SIDE PANEL, LH	1	
5	296276-358	RADIATOR PANEL	1	
6	296276-356	ACCESS PANEL	1	
7	296276-348	FIXED PANEL	1	
8	296276-363	FUEL TANK SUPPORT	1	
9	296276-361	CONTROL PANEL	1	
10	296276-379	HINGE	1	
11	296276-355	CONTROL PANEL GUARD	1	
12	296276-357	CONTROL PANEL COVER WELDMENT	1	
13	296273-081	ROD, PROP	1	
14	296276-344	COVER	1	
15	296276-360	HINGE	1	
16	296276-354	AIR CYLINDER PLATE	2	
17	296271-857	SPRING BRACKET	4	
18	296271-833	STUD, BALL	4	
19	296271-831	AIR CYLINDER, MAIN DOOR	2	
20	296276-409	HOSE MOUNT	1	
21	296271-859	HANDLE	1	
22	296271-858	DOOR LATCH (LARGE)	1	
23	229229-059	DOOR LOCK (SHORT)	1	
24	296276-365	CRASH BAR	2	
25	296276-366	HOSE SADDLE, TOP	1	
26	296276-367	BATTERY BRACKET	1	
27	248848-001	BOLT, J- 1/4-20 X 9	2	
28	296276-417	SUPPORT, GRILL	1	
29	296276-375	BAFFLE, RADIATOR	2	
30	296276-376	PANEL, RADIATOR	2	
31	296276-351	BRACKET, WATER TANK	1	
32	98436-001	GASKET, DOOR (COMES IN 17' LENGTH)	1	
33	248847-001	TRIM SEAL 3/8 BULB	5	
34	248912-001	TRIM SEAL 3/8 BULB 90 DEGREE	1	
NS	409-001	NUT, 5/16-18 TOP LOCK	12	
NS	351-010	BOLT, HX HD 5/16-18 X 1	8	
NS	485-005	WASHER, FLAT 5/16	8	
NS	403-001	NUT, 1/4-20 TOP LOCK	53	
NS	296271-761	BOLT, CARRIAGE 1/4-20 X 3/4	44	
NS	485-003	WASHER, FLAT 1/4, DP1294	45	
NS	229229-393	BOLT, HX HD SER FLG 1/4-20 X 3/4	46	
NS	416-001	NUT, 3/8-16 TOP LOCK	11	
NS	485-007	WASHER, FLAT 3/8	6	
NS	229229-017	BOLT, FLANGE 3/8-16 X 1	12	
NS	4473-004	BOLT, HX HD SER FLG 1/4-20 X 1/2	6	
NS	354-034	BOLT, HX HD 3/8-16 X 3-1/2	1	

POWER PACK, 73 - FUEL & ENGINE ASSEMBLY

Figure 10




POWER PACK, 73 HP - FUEL & ENGINE ASSEMBLY

NO.	PART NO.	DESCRIPTION	QTY	COMMENTS
1	296273-227	ENGINE, KUBOTA - V3300	1	
2	296276-414	ISOLATOR, ENGINE	4	
3	296276-359	ENGINE	2	
4	296276-415	ENGINE MOUNT BRACKET	2	
5	296276-372	AIR CLEANER SPACER BRACKET	1	
6	296276-364	LIFT BAR	1	
7	296260-388	FUEL TANK	1	
8	279326-001	CAP, DIESEL FUEL W/ LOCK	1	
9	142410-001	BOX, LITERATURE	1	
10	296276-378	FUEL TANK STRAP	2	
11	296276-420	EXHAUST PIPE	1	
12	296276-422	MUFFLER CLAMP, 3	1	
13	296276-381	TUBE, AIR INTAKE	1	
14	296271-976	ELBOW, 1/4" NPT X 1/4" BARB	1	
15	296271-970	ELBOW, 1/4" NPT X 5/16" BARB	1	
16	296276-482	HOSE, FUEL, 5/16	1	
17	296276-483	HOSE, FUEL, 3/16	1	
18	1578-001	CLAMP, HOSE 1/4	4	
19	296276-454	BOLT, HX HD M12- 1.25mm X 30mm	12	
20	296271-785	WASHER, 1/2" SAE HARDENED YELLOW ZINC	28	
21	75381-014	BOLT, HX HD 1/2-13x1.5 Gr.8	2	
22	423-001	NUT, 1/2-13 TOP LOCK	12	
23	485-011	WASHER, 1/2" FLAT, DP1494	12	
24	913-0230	HOSE CLAMP #48	2	
25	350-034	Bolt, HX HD 1/4-20x3.5	2	
NS	377-010	BOLT, CARRIAGE 1/2-13 X 1	8	
NS	296271-776	SCREW, PHILLIPS 10-32NF X 5/8" BLACK OXIDE	12	

POWER PACK, 73 - ENGINE ASSEMBLY

Figure 11




POWER PACK, 73 HP - ENGINE ASSEMBLY

NO.	PART NO.	DESCRIPTION	QTY.	COMMENT
1	296273-228	FILTER, OIL	1	
2	296273-229	FILTER, FUEL	1	
3	296276-418	SILENCER	1	
4	296276-419	FLEX PIPE	1	
5	296276-421	BOLT KIT	4	
6	296276-423	TANK OVERFLOW	1	
7	296276-424	AIR CLEANER ASSEMBLY	1	
	296273-230	FILTER, AIR (MAIN)	1	
	296273-231	FILTER, AIR (PRE)	1	
8	296276-425	PRE CLEANER ASSEMBLY	1	
9	296276-426	HOSE, INTAKE	1	
10	296276-427	ELBOW, 3" INTAKE, 90	1	
11	296276-428	AIR CLEANER CONNECTOR	1	
12	296276-429	ENGINE, KUBOTA, V3300	1	
13	296276-431	THROTTLE CABLE	1	
14	296276-432	RADIATOR	1	
15	296276-433	RADIATOR SUPPORT KIT	1	
16	296276-434	RADIATOR STAY BRACKET	1	
17	296276-435	SOLENOID STOP	1	
18	296276-436	GASKET, FUEL FILTER	1	
19	296276-437	ALTERNATOR	1	
20	296276-438	BELT, V	1	
21	296276-439	STARTER ASSEMBLY	1	
22	218420-039	SWITCH, OIL	1	
23	296276-440	WATER PUMP	1	
24	296276-441	GASKET, WATER PUMP	1	
25	296276-442	SUPPORT, WATER PUMP ASSEMBLY	1	
26	296276-443	FAN	1	
27	296276-444	GASKET, MUFFLER	1	
28	296276-445	REDUCER	1	
29	296274-783	SWITCH, TEMPERATURE	1	
30	296274-782	SWITCH, IGNITION	1	

POWER PACK, 73 HP - HYDRAULIC ASSEMBLY

Figure 12




POWER PACK, 73 HP - HYDRAULIC ASSEMBLY

NO.	PART NO.	DESCRIPTION	QTY	COMMENTS
1	296276-413	PUMP, HYDRAULIC	1	
2	506034-040	BOLT, M12-1.75 X 40mm	4	
3	296276-399	TEE, 4MJ X 4MB X 4MJ	2	
4	296271-999	ELBOW, 6MJ X 6MB 90 DEGREE	1	
5	296276-382	BREATHING CAP ASSEMBLY	1	
6	296276-349	HYDRAULIC TANK	1	
7	296276-402	FLANGE KIT, SPLIT 1" CODE 62	1	
8	290765-001	ELBOW, 10MJ - 10MB 90 DEGREE	3	
9	296271-870	SUCTION SCREEN, OIL TANK	1	
10	296276-350	OIL COOLER	1	
11	229229-245	ISOLATOR, COOLER	4	
12	296276-408	PUMP, AUX	1	
13	286533-001	ADAPTER, 6MB-4MJ 90	1	
14	296274-874	ADAPTER, 10MJ - 10MB	1	
15	296276-397	ELBOW, 32 MB X 32 STEM 90 DEGREE	1	
16	296271-877	PRESSURE GAUGE, 5000 PSI	1	
17	296273-085	VALVE, RELIEF ASSY	1	
18	296276-352	FILTER HOUSING ASSEMBLY*	1	Ser # 10011 and lower
	296276-380	HYDRAULIC FILTER CARTRIDGE	1	
19	296276-368	STRAP, HYDRAULIC TANK	2	
20	296273-066	VALVE, POPPET	2	
21	296276-394	ELBOW, 32 FLANGE X 32 HOSE STM	1	
22	286699-001	CLAMP, HOSE 1-1/2	1	
23	296276-412	PLATE, COVER, 1.5	1	
24	296276-387	HOSE, 2" X 52	1	
25	296276-383	ELBOW, 10MJ X 12 MB 90	1	
26	296276-407	CAP, COUPLER MALE 1	1	
27	59423-001	ADAPTER, 4MJ X 4MB 90 DEGREE	2	
28	296273-076	REDUCER, 6MB X 4FB	2	
29	290846-001	ADAPTER, 12MJ X 12 MB	1	
30	296276-396	CLAMP, T-BOLT 2-1/2" HOSE	2	
31	296276-403	FLANGE KIT, SPLIT 2" CODE 61	1	
32	293804-001	PLUG, -06MB	1	
33	296273-078	HOSE, 3/8" X 23	1	
34	296276-401	COUPLER, MALE 1	1	
35	296276-400	TEE, 6MJ X 6MB X 6MJ	1	
36	296276-389	HOSE, 1" X 480	1	
37	296273-074	HOSE, 1/4" X 23	3	
38	296273-079	HOSE, 1/4" X 14	1	
39	296276-398	ELBOW, 16MJ X 16 FLANGE	1	
40	296276-384	HOSE, 1" X 23	1	
41	296276-395	CLAMP, T-BOLT 1-3/8" HOSE	2	
42	296276-390	HOSE, 3/8" X 16	2	
43	296276-385	HOSE, 5/8" X 25	1	
44	296276-386	HOSE, 5/8" X 64	1	
45	296276-388	HOSE, 5/8" X 36	1	
46	296276-392	ADAPTER, 12MB X 1" STEM	1	
47	296276-393	ADAPTER, 16MB X 1" STEM	1	
NS	296271-785	WASHER, 1/2" SAE HARDENED YELLOW ZINC	28	
NS	75381-014	BOLT, HX HD 1/2-13 X 1-1/2" GR8	12	
NS	485-011	WASHER, 1/2" FLAT, DP1494	12	
NS	377-010	BOLT, CARRIAGE 1/2-13 X 1	8	

Figure 1

POWER PACK, 73 HP - ELECTRICAL ASSEMBLY

Figure 13



POWER PACK, 73 HP - ELECTRICAL ASSEMBLY

NO.	PART NO.	DESCRIPTION	QTY	COMMENTS
1	296276-416	BATTERY	1	
2	296271-772	SWITCH, EMERGENCY STOP	1	
3	296271-773	MODULE, WARNING LIGHT	1	
4	201785-001	TACH/ HOURMETER	1	
5	5537-001	TOGGLE BOOT	1	
6	229229-335	RECEPTACLE 12VDC	1	
7	67292-001	SWITCH, TOGGLE SPST	1	
9	279829-001	TEMP SWITCH, 210 DEGREE	1	
10	296276-377	WIRE HARNESS, PP73	1	
11	296273-069	CIRCUIT BREAKER, 30 AMP	1	
12	296276-373	BATTERY CABLE, POSITIVE, 0 GA	1	
14	296271-768	RETURN FILTER PRESSURE SWITCH	1	
15	296276-374	BATTERY CABLE, 0 GA NEGATIVE	1	
16	296278-468	CORRUGATED LOOM 47 1/2	1	
NS	296271-776	SCREW, PHILLIPS 10-32NF X 5/8" BLACK OXIDE	12	
NS	296271-777	NUT, 10-32 NF TOP LOCK	6	

NUMMERICAL INDEX

PART NO.	ITEM-PAGE	PART NO.	ITEM-PAGE	PART NO.	ITEM-PAGE
108500-001	4-17	290997-001	15-9	296271-939	21-7
123645-001	5-7	293804-001	32-25	296271-940	19-7
142410-001	35-15, 9-21	296253-038	7-13	296271-941	18-7
1578-001	67-11, 18-21	296260-388	7-21	296271-942	22-7
201785-001	4-27	296263-838	34-9	296271-943	4-7
215914-001	57-11	296267-599	30-13	296271-944	30-7
218420-015	10-13	296267-602	22-13	296271-945	12-7
218420-037	2-13	296267-625	10-9	296271-946	25-7
218420-039	32-13, 22-23	296267-750	31-7	296271-947	27-7
218420-055	6-13	296270-612	32-7	296271-948	28-7
225861-001	27-9	296270-643	6-3	296271-949	17-7
227241-005	9-13	296270-644	4-3, 35-7	296271-950	1-7
227241-011	18-13	296270-645	10-3	296271-951	14-7
227241-021	29-13	296271-761	24-9	296271-952	23-7
227241-033	8-13	296271-768	38-9, 14-27	296271-953	71-11
227241-041	24-13	296271-772	54-11, 2-27	296271-961	22-9
229229-059	9-15, 23-19	296271-773	52-11, 3-27	296271-964	18-9
229229-193	69-11	296271-775	6-9	296271-969	66-11
229229-195	62-11	296271-776	74-11	296271-970	15-21
229229-197	65-11	296271-782	72-11	296271-972	40-9
229229-245	8-9, 11-25	296271-785	28-9, 20-21	296271-976	14-21
229229-309	47-11	296271-817	5-17	296271-999	22-17, 4-25
229229-335	58-11, 6-27	296271-819	26-17	296273-050	1-15
229229-373,	69-11	296271-826	26-9	296273-051	60-11
2326-756	16-3	296271-827	31-15	296273-052	2-15
241194-001	16-9	296271-831	24-15, 19-19	296273-053	3-15
248841-001	1-17	296271-833	22-15, 18-19	296273-054	4-15
248844-001	2-17	296271-854	10-15	296273-055	5-15
248845-001	3-17	296271-857	21-15, 17-19	296273-056	6-15
248847-001	19-15, 33-19	296271-858	8-15, 22-19	296273-057	15-15
248848-001	12-9, 27-19	296271-859	11-15, 21-19	296273-059	26-15
248849-001	28-17	296271-869	21-9	296273-060	7-15
248867-001	14-15	296271-870	37-9, 9-25	296273-061	13-15
248890-001	15-7	296271-871	36-9	296273-062	12-15
248912-001	39-15, 34-19	296271-872	3-9	296273-063	17-15
248922-001	59-11	296271-873	4-9	296273-064	16-15
251769-001	29-9	296271-874	7-9	296273-065	14-9
277241-038	23-13	296271-877	16-25	296273-066	50-11, 20-25
279326-001	8-21	296271-927	36-7	296273-067	5-9
279829-001	31-9, 9-27	296271-928	3-7	296273-069	39-9, 11-27
286533-001	13-25	296271-929	6-7	296273-070	44-11
286699-001	22-25	296271-930	7-7	296273-071	45-11
287563-00301	9-9	296271-931	9-7	296273-072	34-15
287564-001	32-9	296271-932	10-7	296273-073	42-11
290504-001	20-9	296271-933	8-7	296273-074	14-17, 30-17, 37-25
290765-001	8-25	296271-934	11-7	296273-075	24-17
290846-001	29-25	296271-935	26-7	296273-076	17-17, 28-25
290853-001	2-7	296271-936	24-7	296273-077	19-17
290908-001	68-11	296271-937	16-7	296273-078	23-17, 33-25
		296271-938	20-7		

NUMERICAL INDEX

HYDRAULIC POWER SUPPLY UNITS

PART NO.	ITEM-PAGE
296273-079	20-17, 38-25
296273-080	33-15
296273-081	41-15, 13-19
296273-082	23-15
296273-084	11-9
296273-085	48-11, 17-25
296273-086	7-17
296273-087	9-17
296273-088	6-17
296273-090	10-17
296273-091	13-17
296273-092	12-17
296273-093	25-17
296273-095	13-9
296273-097	61-11
296273-098	63-11
296273-099	64-11
296273-100	18-15
296273-221	31-17
296273-222	29-17
296273-227	1-21
296273-228	1-23
296273-229	2-23
296273-230	7-23
296273-231	7-23
296274-780	46-11
296274-781	31-13
296274-782	25-13, 30-23
296274-783	33-13, 29-23
296274-784	19-13
296274-785	20-13
296274-786	27-13
296274-788	15-13
296274-789	16-13
296274-790	28-13
296274-791	13-13
296274-792	14-13
296274-794	11-13
296274-795	12-13
296274-796	32-17
296274-870	27-17
296274-874	14-25
296274-881	70-11
296274-884	18-17
296274-887	15-17
296274-910	1-9
296274-911	2-9
296274-912	75-11
296274-913	76-11
296276-343	2-19
296276-344	14-19
296276-345	1-19
296276-346	3-19

PART NO.	ITEM-PAGE
296276-347	4-19
296276-348	7-19
296276-349	6-25
296276-350	10-25
296276-351	31-19
296276-352	18-25
296276-354	16-19
296276-355	11-19
296276-356	6-19
296276-357	12-19
296276-358	5-19
296276-359	3-21
296276-360	15-19
296276-361	9-19
296276-363	8-19
296276-364	6-21
296276-365	24-19
296276-366	25-19
296276-367	26-19
296276-368	19-25
296276-370	18-3
296276-371	19-3
296276-372	5-21
296276-373	12-27
296276-374	15-27
296276-375	29-19
296276-376	30-19
296276-377	10-27
296276-378	10-21
296276-379	10-19
296276-380	18-25
296276-381	13-21
296276-382	5-25
296276-383	25-25
296276-384	40-25
296276-385	43-25
296276-386	44-25
296276-387	24-25
296276-388	45-25
296276-389	36-25
296276-390	42-25
296276-394	21-25
296276-395	41-25
296276-396	30-25
296276-397	15-25
296276-398	39-25
296276-399	3-25
296276-400	35-25
296276-401	34-25
296276-402	7-25
296276-403	31-25
296276-407	26-25
296276-408	12-25

PART NO.	ITEM-PAGE
296276-409	20-19
296276-412	23-25
296276-413	1-25
296276-414	2-21
296276-415	4-21
296276-416	1-27
296276-417	28-19
296276-418	3-23
296276-419	4-23
296276-420	11-21
296276-421	5-23
296276-422	12-21
296276-423	6-23
296276-424	7-23
296276-425	8-23
296276-426	9-23
296276-427	10-23
296276-428	11-23
296276-429	12-23
296276-431	13-23
296276-432	14-23
296276-433	15-23
296276-434	16-23
296276-435	17-23
296276-436	18-23
296276-437	19-23
296276-438	20-23
296276-439	21-23
296276-440	23-23
296276-441	24-23
296276-442	25-23
296276-443	26-23
296276-444	27-23
296276-445	28-23
296276-446	12-3
296276-454	19-21
296276-455	1-3
296276-469	7-3
296276-470	9-3
296276-471	14-3
296276-472	2-3
296276-473	41-11
296276-476	22-3, 34-7
296276-477	5-3
296276-478	17-3
296276-479	3-3
296276-480	20-15
296276-481	20-3
296276-482	16-21
296276-483	17-21
296276-492	8-3
296278-460	3-13
296278-461	5-13

PART NO.	ITEM-PAGE
296278-462	1-13
296278-464	4-13
296278-465	17-13
296278-466	21-13
296278-467	26-13
296278-468	15-27
2986274-782	53-11
350-020	49-11
350-034	21-21
354-032	43-11
358-012	30-9
375-010	29-15
403-001	25-9
406-001	35-9
409-001	17-9
416-001	77-11
423-001	22-21
4473-004	25-15
4474-006	23-9
4475-006	19-9
485-011	23-21
485-017	33-7
506034-040	2-25
510-049	38-15
53837-001	11-17
5537-001	51-11, 5-27
59423-001	21-17, 27-25
60908-001	16-17
67292-001	55-11, 7-27
70000098	13-3
70000-294	15-3
70000-684	11-3, 13-7
75925-001	33-9
85658-001	8-17
913-0230	24-21
98436-001	40-15, 32-19

ALPHABETICAL INDEX

DESCRIPTION	PART NO.	ITEM-PAGE
A		
ACCESS PANEL	296276-356	6-19
ADAPTER, 10MB X 12BARB	296271-948	28-7
ADAPTER, 10MB X 8FP	296271-933	8-7
ADAPTER, 10MJ - 10MB	296274-874	14-25
ADAPTER, 12MJ X 12 MB	290846-001	29-25
ADAPTER, 12MJ X 16MB	296273-088	6-17
ADAPTER, 12MJ X 20MB	85658-001	8-17
ADAPTER, 12MP X 12 BARB	296271-947	27-7
ADAPTER, 20MB X 1-1/4" BARB	296274-796	32-17
ADAPTER, 20MB X 16FP	296271-819	26-17
ADAPTER, 32MB X 20FB	296271-817	5-17
ADAPTER, 4MJ X 4MB 90 DEGREE	59423-001	21-17, 27-25
ADAPTER, 4MJ X 4MB	60908-001	16-17
ADAPTER, 4MJ X 6MB	296274-887	15-17
ADAPTER, 6MB-4MJ 90	286533-001	13-25
ADAPTER, 6MJ X 6MB	296274-884	18-17
ADAPTER, HYD PUMP	296274-789	16-13
AIR CLEANER ASSEMBLY	296276-424	7-23
AIR CLEANER ASSY	296253-038	7-13
AIR CLEANER CONNECTOR	296276-428	11-23
AIR CLEANER SPACER	296276-372	5-21
BRACKET		
AIR CLEANER SUPPORT	296274-910	1-9
AIR CYLINDER PLATE	296276-354	16-19
AIR CYLINDER, MAIN DOOR	296271-831	24-15, 19-19
ALTERNATOR	218420-037	2-13
ALTERNATOR	296276-437	19-23
B		
BACK PANEL	296273-052	2-15
BACK PANEL	296276-343	2-19
BAFFLE, RADIATOR	296273-082	23-15
BAFFLE, RADIATOR	296276-375	29-19
BASE FRAME WELDMENT	296273-050	1-15
BASE FRAME WELDMENT	296276-345	1-19
BATTERY BRACKET	296276-367	26-19
BATTERY CABLE, 0 GA NEGATIVE	296276-374	15-27
BATTERY CABLE, 4GA NEGATIVE	296273-071	45-11
BATTERY CABLE, 4GA POSITIVE	296273-070	44-11
BATTERY CABLE, POSITIVE, 0 GA	296276-373	12-27

DESCRIPTION	PART NO.	ITEM-PAGE
BATTERY, 12V GROUP 24 TOP POST 575 CC AMPS	296267-625	10-9
BATTERY	296276-416	1-27
BELT, V	296276-438	20-23
BOLT KIT	296276-421	5-23
BOLT, J- 1/4-20 X 9	248848-001	12-9
BOOT, STRAIGHT CLAMP	296276-473	41-11
BOOT, STUD TERMINAL	296274-881	70-11
BOX, LITERATURE	142410-001	35-15, 9-21
BRACKET, BATTERY	296273-084	11-9
BRACKET, GRILL	296273-080	33-15
BRACKET, HOSE	248867-001	14-15
BRACKET, MUFFLER SUPPORT	296273-065	14-9
BRACKET, WATER RESERVE TANK	296274-784	19-13
BRACKET, WATER TANK	296276-351	31-19
BREATHING CAP ASSEMBLY	296276-382	5-25
BULKHEAD, 12MJ 90 DEGREE	108500-001	4-17
BUSHING, 8MP X 4FP	296271-943	4-7
C		
CABLE, THROTTLE	296274-780	46-11
CABLE, THROTTLE	296278-467	26-13
CAGE	296271-927	36-7
CAP, COUPLER MALE 1	296276-407	26-25
CAP, DIESEL FUEL W/ LOCK	279326-001	8-21
CAP, FUEL	225861-001	27-9
CAP, VALVE COVER	227241-005	9-13
CAP	296271-936	24-7
CIRCUIT BREAKER, 30 AMP	296273-069	39-9, 11-27
CLAMP, EXHAUST 1-1/2	290997-001	15-9
CLAMP, HOSE 1/2	290908-001	68-11
CLAMP, HOSE 1/4	1578-001	67-11, 18-21
CLAMP, HOSE 1-1/2	286699-001	22-25
CLAMP, HOSE 1-3/4	296271-952	23-7
CLAMP, T-BOLT 1-1/2	248849-001	28-17
CLAMP, T-BOLT 1-3/8" HOSE	296276-395	41-25
CLAMP, T-BOLT 2-1/2" HOSE	296276-396	30-25
CONTROL PANEL COVER WELDMENT	296276-357	12-19
CONTROL PANEL GUARD	296276-355	11-19
CONTROL PANEL HOUSING	296273-064	16-15
CONTROL PANEL WELDMENT	296273-063	17-15
CONTROL PANEL	296276-361	9-19
COTTER PIN 3/16 X 1-1/14	296270-612	32-7
COUPLER, ENGINE	296271-940	19-7
COUPLER, MALE 1	296276-401	34-25

DESCRIPTION	PART NO.	ITEM-PAGE
COUPLER, PUMP	296271-941	18-7
COUPLING, 3/4 FLUSH FACE	248844-001	2-17
COVER WELDMENT	296273-053	3-15
COVER, CONTROL PANEL WELDMENT	296273-056	6-15
COVER	296276-344	14-19
CRASH BAR	296276-365	24-19
D		
DECAL WWW. HAMMERHEAD LARGE 12 X 8 TRIANGLE	296270-645	10-3
DECAL, CONTROL PANEL, PP20	296276-478	17-3
DECAL, CONTROL PANEL, PP73	296276-371	19-3
DECAL, COOLANT WARNING	296276-472	2-3
DECAL, DIESEL FUEL	70000098	13-3
DECAL, FALLING LOAD	296276-469	7-3
DECAL, FUSE PANEL, PP20	296276-479	3-3
DECAL, FUSE, PP73	296276-481	20-3
DECAL, HAMMERHEAD 30	296270-643	6-3
DECAL, HYDRAULIC OIL, PP20	2326-756	16-3
DECAL, LIFT POINT (LARGE)	296276-492	8-3
DECAL, OPERATOR'S MANUAL	70000-294	15-3
DECAL, PP20	296276-477	5-3
DECAL, PP73	296276-370	18-3
DECAL, READ OPERATOR'S MANUAL	70000-684	11-3, 13-7
DECAL, REFUELING WARNING	296276-471	14-3
DECAL, TIE DOWN (SMALL)	296276-455	1-3
DECAL, VALVE CONTROL	296276-476	22-3, 34-7
DECAL, WARNING (BATTERY)	296276-470	9-3
DECAL, WARNING, (ONE-CALL)	296276-446	12-3
DECAL, WWW. HAMMERHEAD 6 X 4 TRIANGLE	296270-644	4-3
DECAL, WWW.HAMMERHEAD 6X4 TRIANGLE	296270-644	35-7
DOOR LATCH (LARGE)	296271-858	8-15, 22-19
DOOR LOCK (SHORT)	229229-059	9-15, 23-19
E		
ELBOW, 1/4" NPT X 1/4" BARB	296271-976	14-21
ELBOW, 1/4" NPT X 5/16" BARB	296271-970	15-21
ELBOW, 10MJ - 10MB 90 DEGREE	290765-001	8-25
ELBOW, 10MJ X 12 MB 90	296276-383	25-25

DESCRIPTION	PART NO.	ITEM-PAGE
ELBOW, 1-1/4" HOSE INSERT	296273-221	31-17
ELBOW, 12 MP X 12BARB 90 DEGREE	296271-945	12-7
ELBOW, 12MP X 8FP 45 DEGREE	296271-930	7-7
ELBOW, 12MP-12MP X 90	123645-001	5-7
ELBOW, 16MJ X 16 FLANGE	296276-398	39-25
ELBOW, 3" INTAKE, 90	296276-427	10-23
ELBOW, 32 FLANGE X 32 HOSE STM	296276-394	21-25
ELBOW, 32 MB X 32 STEM 90 DEGREE	296276-397	15-25
ELBOW, 6MJ X 6MB 90 DEGREE	296271-999	22-17, 4-25
ELBOW, 8MJ X 10MB 90 DEGREE	296273-092	12-17
ELBOW, 8MJ X 8MB 90 DEGREE	53837-001	11-17
ELBOW, HOSE 3/8	287564-001	32-9
ELEMENT, AIR FILTER	296267-602	22-13
ENGINE MOUNT BRACKET	296276-359	3-21
ENGINE MOUNT BRACKET	296276-415	4-21
ENGINE, 13 HP HONDA	296271-949	17-7
ENGINE, KUBOTA - V3300	296273-227	1-21
ENGINE, KUBOTA D905	296273-067	5-9
ENGINE, KUBOTA, V3300	296276-429	12-23
EXHAUST PIPE	296273-095	13-9
EXHAUST PIPE	296276-420	11-21
F		
FAN	296276-443	26-23
FAN	296278-464	4-13
FILTER HEAD	296271-929	6-7
FILTER HOUSING ASSEMBLY	296276-352	18-25
FILTER, AIR (MAIN)	296273-230	7-23
FILTER, AIR (PRE)	296273-231	7-23
FILTER, ENGINE OIL	227241-021	29-13
FILTER, FUEL	296271-972	40-9
FILTER, FUEL	296273-229	2-23
FILTER, OIL	296273-228	1-23
FILTER	296271-931	9-7
FITTING, 1/4" NPT X 3/16" BARB	229229-195	62-11
FITTING, 1/4" X 1/4 NPT BARB	229229-197	65-11
FIXED PANEL	296276-348	7-19
FLANGE KIT, SPLIT 1" CODE 62	296276-402	7-25
FLANGE KIT, SPLIT 2" CODE 61	296276-403	31-25
FLEX PIPE	296276-419	4-23
FOAM, PANEL - CUT FROM ROLL	296273-072	34-15
FUEL FILTER	296278-460	3-13

ALPHABETICAL INDEX

HYDRAULIC POWER SUPPLY UNITS

DESCRIPTION	PART NO.	ITEM-PAGE
FUEL FILTER	296278-461	5-13
FUEL PUMP	218420-055	6-13
FUEL TANK STRAP	296276-378	10-21
FUEL TANK SUPPORT	296273-057	15-15
FUEL TANK SUPPORT	296276-363	8-19
FUEL TANK	287563-00301	9-9
FUEL TANK	296260-388	7-21
G		
GASKET, DOOR (COMES IN 17' LGTH)	98436-001	40-15
GASKET, DOOR	98436-001	32-19
GASKET, FUEL FILTER	296276-436	18-23
GASKET, MUFFLER	296276-444	27-23
GASKET, OIL PAN PLUG	296274-792	14-13
GASKET, STOP SOLENOID	227241-041	24-13
GASKET, THERMOSTAT	296274-795	12-13
GASKET, WATER PUMP	296276-441	24-23
GASKET-MUFFLER	227241-011	18-13
GROMMET	75925-001	33-9
GUAGE, 3000 PSI PRESSURE	248890-001	15-7
H		
HANDLE	296271-859	11-15, 21-19
HEAD, FILTER	296271-872	3-9
HINGE, 12.25	296271-854	10-15
HINGE, 28.75	296273-061	13-15
HINGE, 9.75	296273-062	12-15
HINGE	296276-360	15-19
HINGE	296276-379	10-19
HOSE ASSY, 3/4" X 300	248841-001	1-17
HOSE CLAMP #48	913-0230	24-21
HOSE MOUNT	296276-409	20-19
HOSE SADDLE, TOP	296276-366	25-19
HOSE, 1" X 23	296276-384	40-25
HOSE, 1" X 480	296276-389	36-25
HOSE, 1/2" X 25	296273-090	10-17
HOSE, 1/4" X 14	296273-079	20-17, 38-25
HOSE, 1/4" X 23	296273-074	14-17, 37-25
HOSE, 1/4" X 4	296273-097	61-11
HOSE, 1/4" X 48	296273-098	63-11
HOSE, 1-1/4" X 41	296273-222	29-17
HOSE, 2" X 52	296276-387	24-25
HOSE, 3/16" X 54	296273-099	64-11
HOSE, 3/4" X 17	296273-091	13-17
HOSE, 3/4" X 54	296273-086	7-17
HOSE, 3/4" X 55	296273-087	9-17
HOSE, 3/8" X 16	296276-390	42-25
HOSE, 3/8" X 23	296273-075	24-17

DESCRIPTION	PART NO.	ITEM-PAGE
HOSE, 3/8" X 23	296273-078	23-17, 33-25
HOSE, 5/8" X 25	296276-385	43-25
HOSE, 5/8" X 36	296276-388	45-25
HOSE, 5/8" X 64	296276-386	44-25
HOSE, AIR CLEANER	296274-781	31-13
HOSE, FUEL, 3/16	296276-483	17-21
HOSE, FUEL, 5/16	296276-482	16-21
HOSE, INTAKE	296276-426	9-23
HOSE, PRESSURE	296271-944	30-7
HOSE, RETURN	296271-946	25-7
HOSE, SUCTION	296271-935	26-7
HOSE, WATER 5/16 X 60	296271-969	66-11
HOSE	296273-074	30-17
HOSE METER	215914-001	57-11
HUB, PUMP DRIVE	296274-788	15-13
HYDRAULIC FILTER CARTRIDGE	296276-380	18-25
HYDRAULIC TANK	296276-349	6-25
I		
ISOLATOR, COOLER	229229-245	8-9, 11-25
ISOLATOR, ENGINE	296276-414	2-21
ISOLATOR, RUBBER 1/2-20 THRD	248922-001	59-11
L		
LIFT BAR	296273-059	26-15
LIFT BAR	296276-364	6-21
LOOM	296278-468	15-27
M		
MODULE, WARNING LIGHT	296271-773	52-11, 3-27
MOTOR MOUNT	296273-051	60-11
MOUNT, HYD. COOLER	296271-827	31-15
MUFFLER CLAMP, 3	296276-422	12-21
MUFFLER	296278-465	17-13
N		
NIPPLE, 3/4" FLUSH FACE	248845-001	3-17
O		
OIL CAP ASSY	296271-871	36-9
OIL COOLER	296271-874	7-9
OIL COOLER	296276-350	10-25
OIL FILTER, 50-AT	296271-873	4-9
OIL TANK TRAY	296274-912	75-11
OIL TANK, 15 GAL	296274-911	2-9
O-RING, VALVE COVER CAP	218420-015	10-13
P		
PANEL, ACCESS	296276-480	20-15
PANEL, LH SIDE	296273-055	5-15
PANEL, RADIATOR	296273-100	18-15
PANEL, RADIATOR	296276-376	30-19
PANEL, RH SIDE	296273-054	4-15

DESCRIPTION	PART NO.	ITEM-PAGE
PIN, COTTER 3/32 X 1	510-049	38-15
PIPE PLUG, SQ HEAD 3/4 GALV	290853-001	2-7
PLATE, COVER, 1.5	296276-412	23-25
PLATE, PUMP	296271-937	16-7
PLUG, -06MB	293804-001	32-25
PLUG, 10MB	296273-093	25-17
PLUG, 2MP	296274-870	27-17
PLUG, OIL PAN DRAIN	296274-791	13-13
PRE CLEANER ASSEMBLY	296276-425	8-23
PRESSURE GAUGE, 5000 PSI	296271-877	16-25
PRESSURE GUAGE, 3000 PSI	229229-309	47-11
PUMP, .388 CU IN	296271-951	14-7
PUMP, AUX	296276-408	12-25
PUMP, HYDRAULIC	296276-413	1-25
PUMP, PVP33 2.0 CI	296271-775	6-9
R		
RADIATOR PANEL	296273-060	7-15
RADIATOR PANEL	296276-358	5-19
RADIATOR STAY BRACKET	296276-434	16-23
RADIATOR SUPPORT KIT	296276-433	15-23
RADIATOR	296276-431	14-23
RADIATOR	296278-466	21-13
RECEPTACLE 12VDC	229229-335	58-11, 6-27
REDUCER, 6MB X 4FB	296273-076	17-17
REDUCER, 6MB X 4FB	59423-001	28-25
REDUCER	296276-445	28-23
RESERVE TANK	296274-785	20-13
RESERVOIR	296271-950	1-7
RETURN FILTER PRESSURE SWITCH	296271-768	38-9, 14-27
ROD, PROP	296273-081	41-15, 13-19
S		
SHIELD	296271-932	10-7
SHROUD, FAN	296274-786	27-13
SIDE PANEL, LH	296276-347	4-19
SIDE PANEL, RH	296276-346	3-19
SILENCER	296276-418	3-23
SOLENOID STOP	296276-435	17-23
SPACER, BOTTOM	296271-942	22-7
SPACER, MOUNT	296271-939	21-7
SPIDER	296271-938	20-7
SPRING BRACKET	296271-857	21-15, 17-19
STARTER ASSEMBLY	296276-439	21-23
STARTER	296278-462	1-13
STOP SOLENOID	277241-038	23-13
STRAP, HYDRAULIC TANK	296276-368	19-25
STRAP, OIL TANK	296274-913	76-11

DESCRIPTION	PART NO.	ITEM-PAGE
STUD, BALL	296271-833	22-15, 18-19
SUCTION SCREEN, OIL TANK	296271-870	37-9, 9-25
SUPPORT, GRILL	296276-417	28-19
SUPPORT, OIL TANK	296273-073	42-11
SUPPORT, WATER PUMP ASSEMBLY	296276-442	25-23
SWITCH, EMERGENCY STOP	296271-772	54-11, 2-27
SWITCH, IGNITION	296274-782	25-13, 30-23
SWITCH, IGNITION	2986274-782	53-11
SWITCH, OIL	218420-039	32-13, 22-23
SWITCH, TEMPERATURE	296274-783	33-13, 29-23
SWITCH, TOGGLE SPST	67292-001	55-11, 7-27
T		
TACH/ HOURMETER	201785-001	4-27
TANK OVERFLOW	296276-423	6-23
TEE, 4MJ X 4MB X 4MJ	296276-399	3-25
TEE, 4MJ X 4MJ X 4MB	296273-077	19-17
TEE, 6MJ X 6MB X 6MJ	296276-400	35-25
TEE, 8MP X 8FP X 8FP	296271-934	11-7
TEMP SWITCH, 210 DEGREE	279829-001	31-9, 9-27
THERMOSTAT	296274-794	11-13
THROTTLE CABLE	296276-431	13-23
TOGGLE BOOT	5537-001	51-11, 5-27
TRIM SEAL 3/8 BULB 90 DEGREE	248912-001	39-15, 34-19
TRIM SEAL 3/8 BULB	248847-001	19-15, 33-19
TUBE, 3/8 ID X 5/8 OD X 11	296263-838	34-9
TUBE, AIR INTAKE	296276-381	13-21
V		
VALVE, POPPET	296273-066	50-11, 20-25
VALVE, RADIATOR DRAIN ASSY	296274-790	28-13
VALVE, RELIEF ASSY	296273-085	48-11, 17-25
VALVE	296271-928	3-7
V-BELT, FAN	296267-599	30-13
W		
WASHER, FLAT 3/4, DP1698	485-017	33-7
WATER PUMP	227241-033	8-13
WATER PUMP	296276-440	23-23

DESCRIPTION	PART NO.	ITEM-PAGE
WHEEL & TIRE ASSEMBLY	296267-750	31-7
WIRE HARNESS, PP73	296276-377	10-27

A

ACCESS PANEL=296276-356 =6-19
 ADAPTER, 10MB X 12BARB=296271-948 =28-7
 ADAPTER, 10MB X 8FP=296271-933 =8-7
 ADAPTER, 10MJ - 10MB=296274-874 =14-25
 ADAPTER, 12MJ X 12 MB=290846-001 =29-25
 ADAPTER, 12MJ X 16MB=296273-088 =6-17
 ADAPTER, 12MJ X 20MB=85658-001 =8-17
 ADAPTER, 12MP X 12 BARB=296271-947 =27-7
 ADAPTER, 20MB X 1-1/4" BARB=296274-796 =32-17
 ADAPTER, 20MB X 16FP=296271-819 =26-17
 ADAPTER, 32MB X 20FB=296271-817 =5-17
 ADAPTER, 4MJ X 4MB 90 DEGREE=59423-001 =21-17, =27-25
 ADAPTER, 4MJ X 4MB=60908-001 =16-17
 ADAPTER, 4MJ X 6MB=296274-887 =15-17
 ADAPTER, 6MB-4MJ 90=286533-001 =13-25
 ADAPTER, 6MJ X 6MB=296274-884 =18-17
 ADAPTER, HYD PUMP=296274-789 =16-13
 AIR CLEANER ASSEMBLY=296276-424 =7-23
 AIR CLEANER ASSY=296253-038 =7-13
 AIR CLEANER CONNECTOR=296276-428 =11-23
 AIR CLEANER SPACER BRACKET=296276-372 =5-21
 AIR CLEANER SUPPORT=296274-910 =1-9
 AIR CYLINDER PLATE=296276-354 =16-19
 AIR CYLINDER, MAIN DOOR=296271-831 =24-15, =19-19
 ALTERNATOR=218420-037 =2-13
 ALTERNATOR=296276-437 =19-23

INDEX

BATTERY CABLE, 4ga NEGATIVE=296273-071 =45-11
 BATTERY CABLE, 4ga POSITIVE=296273-070 =44-11
 BATTERY CABLE, POSITIVE, 0 GA=296276-373 =12-27
 BATTERY, 12V GROUP 24 TOP POST 575 CC AMPS=296267-625 =10-9
 BATTERY=296276-416 =1-27
 BELT, V=296276-438 =20-23
 BOLT KIT=296276-421 =5-23
 BOLT, J- 1/4-20 X 9=248848-001 =12-9
 BOOT, STRAIGHT CLAMP=296276-473 =41-11
 BOOT, STUD TERMINAL=296274-881 =70-11
 BOX, LITERATURE=142410-001 =35-15, =9-21
 BRACKET, BATTERY=296273-084 =11-9
 BRACKET, GRILL=296273-080 =33-15
 BRACKET, HOSE=248867-001 =14-15
 BRACKET, MUFFLER SUPPORT=296273-065 =14-9
 BRACKET, WATER RESERVE TANK=296274-784 =19-13
 BRACKET, WATER TANK=296276-351 =31-19
 BREATHER CAP ASSEMBLY=296276-382 =5-25
 BULKHEAD, 12MJ 90 DEGREE=108500-001 =4-17
 BUSHING, 8MP X 4FP=296271-943 =4-7

C

CABLE, THROTTLE=296274-780 =46-11
 CABLE, THROTTLE=296278-467 =26-13
 CAGE=296271-927 =36-7
 CAP, COUPLER MALE 1=296276-407 =26-25
 CAP, DIESEL FUEL W/ LOCK=279326-001 =8-21
 CAP, FUEL=225861-001 =27-9
 CAP, VALVE COVER=227241-005 =9-13
 CAP=296271-936 =24-7
 CIRCUIT BREAKER, 30 AMP=296273-069 =39-9, =11-27
 CLAMP, EXHAUST 1-1/2=290997-001 =15-9
 CLAMP, HOSE 1/2=290908-001 =68-11
 CLAMP, HOSE 1/4=1578-001 =67-11, =18-21
 CLAMP, HOSE 1-1/2=286699-001 =22-25
 CLAMP, HOSE 1-3/4=296271-952 =23-7
 CLAMP, T-BOLT 1-1/2=248849-001 =28-17
 CLAMP, T-BOLT 1-3/8" HOSE=296276-395 =41-25
 CLAMP, T-BOLT 2-1/2" HOSE=296276-396

=30-25
 CONTROL PANEL COVER WELD-
 MENT=296276-357 =12-19
 CONTROL PANEL GUARD=296276-355 =11-
 19
 CONTROL PANEL HOUSING=296273-064
 =16-15
 CONTROL PANEL WELDMENT=296273-063
 =17-15
 CONTROL PANEL=296276-361 =9-19
 COTTER PIN 3/16 X 1-1/14=296270-612 =32-7
 COUPLER, ENGINE=296271-940 =19-7
 COUPLER, MALE 1=296276-401 =34-25
 COUPLER, PUMP=296271-941 =18-7
 COUPLING, 3/4 FLUSH FACE=248844-001 =2-
 17
 COVER WELDMENT=296273-053 =3-15
 COVER, CONTROL PANEL WELD-
 MENT=296273-056 =6-15
 COVER=296276-344 =14-19
 CRASH BAR=296276-365 =24-19
 D
 DECAL WWW. HAMMERHEAD LARGE 12 X
 8 TRIANGLE=296270-645 =10-3
 DECAL, CONTROL PANEL, PP20=296276-478
 =17-3
 DECAL, CONTROL PANEL, PP73=296276-371
 =19-3
 DECAL, COOLANT WARNING=296276-472
 =2-3
 DECAL, DIESEL FUEL=70000098 =13-3
 DECAL, FALLING LOAD=296276-469 =7-3
 DECAL, FUSE PANEL, PP20=296276-479 =3-3
 DECAL, FUSE, PP73=296276-481 =20-3
 DECAL, HAMMERHEAD 30=296270-643 =6-3
 DECAL, HYDRAULIC OIL, PP20=2326-756
 =16-3
 DECAL, LIFT POINT (LARGE)=296276-492 =8-
 3
 DECAL, OPERATOR'S MANUAL=70000-294
 =15-3
 DECAL, PP20=296276-477 =5-3
 DECAL, PP73=296276-370 =18-3
 DECAL, READ OPERATOR'S MANU-
 AL=70000-684 =11-3, =13-7
 DECAL, REFUELING WARNING=296276-471
 =14-3
~~DECAL, TIE DOWN (SMALL)=296276-455 =1-~~
 3

DECAL, VALVE CONTROL=296276-476 =22-
 3, =34-7
 DECAL, WARNING (BATTERY)=296276-470
 =9-3
 DECAL, WARNING, (ONE-CALL)=296276-446
 =12-3
 DECAL, WWW. HAMMERHEAD 6 X 4 TRIAN-
 GLE=296270-644 =4-3
 DECAL, WWW.HAMMERHEAD 6X4 TRIAN-
 GLE=296270-644 =35-7
 DOOR LATCH (LARGE)=296271-858 =8-15,
 =22-19
 DOOR LOCK (SHORT)=229229-059 =9-15, =23-
 19
 E
 ELBOW, 1/4" NPT X 1/4" BARB=296271-976
 =14-21
 ELBOW, 1/4" NPT X 5/16" BARB=296271-970
 =15-21
 ELBOW, 10MJ - 10MB 90 DEGREE=290765-001
 =8-25
 ELBOW, 10MJ X 12 MB 90=296276-383 =25-25
 ELBOW, 1-1/4" HOSE INSERT=296273-221
 =31-17
 ELBOW, 12 MP X 12BARB 90 DE-
 GREE=296271-945 =12-7
 ELBOW, 12MP X 8FP 45 DEGREE=296271-930
 =7-7
 ELBOW, 12MP-12MP X 90=123645-001 =5-7
 ELBOW, 16MJ X 16 FLANGE=296276-398 =39-
 25
 ELBOW, 3" INTAKE, 90=296276-427 =10-23
 ELBOW, 32 FLANGE X 32 HOSE STM=296276-
 394 =21-25
 ELBOW, 32 MB X 32 STEM 90 DE-
 GREE=296276-397 =15-25
 ELBOW, 6MJ X 6MB 90 DEGREE=296271-999
 =22-17, =4-25
 ELBOW, 8MJ X 10MB 90 DEGREE=296273-092
 =12-17
 ELBOW, 8MJ X 8MB 90 DEGREE=53837-001
 =11-17
 ELBOW, HOSE 3/8=287564-001 =32-9
 ELEMENT, AIR FILTER=296267-602 =22-13
 ENGINE MOUNT BRACKET=296276-359 =3-
 21
 ENGINE MOUNT BRACKET=296276-415 =4-
 21
 ENGINE, 13 HP HONDA=296271-949 =17-7

ENGINE, KUBOTA - V3300=296273-227 =1-21
 ENGINE, KUBOTA D905=296273-067 =5-9
 ENGINE, KUBOTA, V3300=296276-429 =12-23
 EXHAUST PIPE=296273-095 =13-9
 EXHAUST PIPE=296276-420 =11-21
 F
 FAN=296276-443 =26-23
 FAN=296278-464 =4-13
 FILTER HEAD=296271-929 =6-7
 FILTER HOUSING ASSEMBLY=296276-352 =18-25
 FILTER, AIR (MAIN)=296273-230 =7-23
 FILTER, AIR (PRE)=296273-231 =7-23
 FILTER, ENGINE OIL=227241-021 =29-13
 FILTER, FUEL=296271-972 =40-9
 FILTER, FUEL=296273-229 =2-23
 FILTER, OIL=296273-228 =1-23
 FILTER=296271-931 =9-7
 FITTING, 1/4" NPT X 3/16" BARB=229229-195 =62-11
 FITTING, 1/4" X 1/4 NPT BARB=229229-197 =65-11
 FIXED PANEL=296276-348 =7-19
 FLANGE KIT, SPLIT 1" CODE 62=296276-402 =7-25
 FLANGE KIT, SPLIT 2" CODE 61=296276-403 =31-25
 FLEX PIPE=296276-419 =4-23
 FOAM, PANEL - CUT FROM ROLL=296273-072 =34-15
 FUEL FILTER=296278-460 =3-13
 FUEL FILTER=296278-461 =5-13
 FUEL PUMP=218420-055 =6-13
 FUEL TANK STRAP=296276-378 =10-21
 FUEL TANK SUPPORT=296273-057 =15-15
 FUEL TANK SUPPORT=296276-363 =8-19
 FUEL TANK=287563-00301 =9-9
 FUEL TANK=296260-388 =7-21
 G
 GASKET, DOOR (COMES IN 17' LGTH)=98436-001 =40-15
 GASKET, DOOR=98436-001 =32-19
 GASKET, FUEL FILTER=296276-436 =18-23
 GASKET, MUFFLER=296276-444 =27-23
 GASKET, OIL PAN PLUG=296274-792 =14-13
 GASKET, STOP SOLENOID=227241-041 =24-13
~~GASKET, THERMOSTAT=296274-795 =12-13~~
 GASKET, WATER PUMP=296276-441 =24-23

GASKET-MUFFLER=227241-011 =18-13
 GROMMET=75925-001 =33-9
 GUAGE, 3000 PSI PRESSURE=248890-001 =15-7
 H
 HANDLE=296271-859 =11-15, =21-19
 HEAD, FILTER=296271-872 =3-9
 HINGE, 12.25=296271-854 =10-15
 HINGE, 28.75=296273-061 =13-15
 HINGE, 9.75=296273-062 =12-15
 HINGE=296276-360 =15-19
 HINGE=296276-379 =10-19
 HOSE ASSY, 3/4" X 300=248841-001 =1-17
 HOSE CLAMP #48=913-0230 =24-21
 HOSE MOUNT=296276-409 =20-19
 HOSE SADDLE, TOP=296276-366 =25-19
 HOSE, 1" X 23=296276-384 =40-25
 HOSE, 1" X 480=296276-389 =36-25
 HOSE, 1/2" X 25=296273-090 =10-17
 HOSE, 1/4" X 14=296273-079 =20-17, =38-25
 HOSE, 1/4" X 23=296273-074 =14-17, =37-25
 HOSE, 1/4" X 4=296273-097 =61-11
 HOSE, 1/4" x 48=296273-098 =63-11
 HOSE, 1-1/4" X 41=296273-222 =29-17
 HOSE, 2" X 52=296276-387 =24-25
 HOSE, 3/16" X 54=296273-099 =64-11
 HOSE, 3/4" X 17=296273-091 =13-17
 HOSE, 3/4" X 54=296273-086 =7-17
 HOSE, 3/4" X 55=296273-087 =9-17
 HOSE, 3/8" X 16=296276-390 =42-25
 HOSE, 3/8" X 23=296273-075 =24-17
 HOSE, 3/8" X 23=296273-078 =23-17, =33-25
 HOSE, 5/8" X 25=296276-385 =43-25
 HOSE, 5/8" X 36=296276-388 =45-25
 HOSE, 5/8" X 64=296276-386 =44-25
 HOSE, AIR CLEANER=296274-781 =31-13
 HOSE, FUEL, 3/16=296276-483 =17-21
 HOSE, FUEL, 5/16=296276-482 =16-21
 HOSE, INTAKE=296276-426 =9-23
 HOSE, PRESSURE=296271-944 =30-7
 HOSE, RETURN=296271-946 =25-7
 HOSE, SUCTION=296271-935 =26-7
 HOSE, WATER 5/16 X 60=296271-969 =66-11
 HOSE=296273-074 =30-17
 HOUR METER=215914-001 =57-11
 HUB, PUMP DRIVE=296274-788 =15-13
 HYDRAULIC FILTER CARTRIDGE=296276-380 =18-25
 HYDRAULIC TANK=296276-349 =6-25

- I
ISOLATOR, COOLER=229229-245 =8-9, =11-25
ISOLATOR, ENGINE=296276-414 =2-21
ISOLATOR, RUBBER 1/2-20 THRD=248922-001 =59-11
- L
LIFT BAR=296273-059 =26-15
LIFT BAR=296276-364 =6-21
LOOM=296278-468 =15-27
- M
MODULE, WARNING LIGHT=296271-773 =52-11, =3-27
MOTOR MOUNT=296273-051 =60-11
MOUNT, HYD. COOLER=296271-827 =31-15
MUFFLER CLAMP, 3=296276-422 =12-21
MUFFLER=296278-465 =17-13
- N
NIPPLE, 3/4" FLUSH FACE=248845-001 =3-17
- O
OIL CAP ASSY=296271-871 =36-9
OIL COOLER=296271-874 =7-9
OIL COOLER=296276-350 =10-25
OIL FILTER, 50-AT=296271-873 =4-9
OIL TANK TRAY=296274-912 =75-11
OIL TANK, 15 GAL=296274-911 =2-9
O-RING, VALVE COVER CAP=218420-015 =10-13
- P
PANEL, ACCESS=296276-480 =20-15
PANEL, LH SIDE=296273-055 =5-15
PANEL, RADIATOR=296273-100 =18-15
PANEL, RADIATOR=296276-376 =30-19
PANEL, RH SIDE=296273-054 =4-15
PIN, COTTER 3/32 X 1=510-049 =38-15
PIPE PLUG, SQ HEAD 3/4 GALV=290853-001 =2-7
PLATE, COVER, 1.5=296276-412 =23-25
PLATE, PUMP=296271-937 =16-7
PLUG, -06MB=293804-001 =32-25
PLUG, 10MB=296273-093 =25-17
PLUG, 2MP=296274-870 =27-17
PLUG, OIL PAN DRAIN=296274-791 =13-13
PRE CLEANER ASSEMBLY=296276-425 =8-23
PRESSURE GAUGE, 5000 PSI=296271-877 =16-25
PRESSURE GAUGE, 3000 PSI=229229-309 =47-11
~~PUMP, 388 CU IN=296271-951 =14-7~~
PUMP, AUX=296276-408 =12-25
- PUMP, HYDRAULIC=296276-413 =1-25
PUMP, PVP33 2.0 CI=296271-775 =6-9
- R
RADIATOR PANEL=296273-060 =7-15
RADIATOR PANEL=296276-358 =5-19
RADIATOR STAY BRACKET=296276-434 =16-23
RADIATOR SUPPORT KIT=296276-433 =15-23
RADIATOR=296276-431 =14-23
RADIATOR=296278-466 =21-13
RECEPTACLE 12VDC=229229-335 =58-11, =6-27
REDUCER, 6MB X 4FB=296273-076 =17-17
REDUCER, 6MB X 4FB=59423-001 =28-25
REDUCER=296276-445 =28-23
RESERVE TANK=296274-785 =20-13
RESERVOIR=296271-950 =1-7
RETURN FILTER PRESSURE SWITCH=296271-768 =38-9, =14-27
ROD, PROP=296273-081 =41-15, =13-19
- S
SHIELD=296271-932 =10-7
SHROUD, FAN=296274-786 =27-13
SIDE PANEL, LH=296276-347 =4-19
SIDE PANEL, RH=296276-346 =3-19
SILENCER=296276-418 =3-23
SOLENOID STOP=296276-435 =17-23
SPACER, BOTTOM=296271-942 =22-7
SPACER, MOUNT=296271-939 =21-7
SPIDER=296271-938 =20-7
SPRING BRACKET=296271-857 =21-15, =17-19
STARTER ASSEMBLY=296276-439 =21-23
STARTER=296278-462 =1-13
STOP SOLENOID=277241-038 =23-13
STRAP, HYDRAULIC TANK=296276-368 =19-25
STRAP, OIL TANK=296274-913 =76-11
STUD, BALL=296271-833 =22-15, =18-19
SUCTION SCREEN, OIL TANK=296271-870 =37-9, =9-25
SUPPORT, GRILL=296276-417 =28-19
SUPPORT, OIL TANK=296273-073 =42-11
SUPPORT, WATER PUMP ASSEMBLY=296276-442 =25-23
SWITCH, EMERGENCY STOP=296271-772 =54-11, =2-27
SWITCH, IGNITION=296274-782 =25-13, =30-23
Switch, Ignition=2986274-782 =53-11

SWITCH, OIL=218420-039 =32-13, =22-23
SWITCH, TEMPERATURE=296274-783 =33-13, =29-23
SWITCH, TOGGLE SPST=67292-001 =55-11, =7-27
T
TACH/ HOURMETER=201785-001 =4-27
TANK OVERFLOW=296276-423 =6-23
TEE, 4MJ X 4MB X 4MJ=296276-399 =3-25
TEE, 4MJ X 4MJ X 4MB=296273-077 =19-17
TEE, 6MJ X 6MB X 6MJ=296276-400 =35-25
TEE, 8MP X 8FP X 8FP=296271-934 =11-7
TEMP SWITCH, 210 DEGREE=279829-001 =31-9, =9-27
THERMOSTAT=296274-794 =11-13
THROTTLE CABLE=296276-431 =13-23
TOGGLE BOOT=5537-001 =51-11, =5-27
TRIM SEAL 3/8 BULB 90 DEGREE=248912-001 =39-15, =34-19
TRIM SEAL 3/8 BULB=248847-001 =19-15, =33-19
TUBE, 3/8 ID X 5/8 OD X 11=296263-838 =34-9
TUBE, AIR INTAKE=296276-381 =13-21
V
VALVE, POPPET=296273-066 =50-11, =20-25
VALVE, RADIATOR DRAIN ASSY=296274-790 =28-13
VALVE, RELIEF ASSY=296273-085 =48-11, =17-25
VALVE=296271-928 =3-7
V-BELT, FAN=296267-599 =30-13
W
WASHER, FLAT 3/4, DP1698=485-017 =33-7
WATER PUMP=227241-033 =8-13
WATER PUMP=296276-440 =23-23
WHEEL & TIRE ASSEMBLY=296267-750 =31-7
WIRE HARNESS, PP73=296276-377 =10-27